

Rover (UK1) Brush Guard removal and Grab Bar Kit installation



Figure #1



Figure #2



Figure #3

Step 1

The Rover (UK1) models come standard with the high brush guard, as shown in the picture to the left. In addition we also offer the shorter Grab Bars Kit for this unit..

Step 2

To install the shorter Grab Bars, the brush guard must be removed.

1. Remove the bolt and nut on each side of the seat for the rear brush guard risers.
2. These bolts are located at the bottom corner of the safety netting, and shown in the Figure #2

Step 3

Next

1. Remove the bolt from each side of the front hood. This allows the entire brush guard to be lifted up for removal.



Rover (UKI) Brush Guard removal and Grab Bar Kit installation



Figure #4



Figure #5



Figure #6

Step 4

Stop brackets are supplied with the Grab Bar Kit. They are marked (L)eft and (R)ight. When installing the new front Grab Bar, these brackets are to be mounted to the lower hole of the front Grab Bar

1. Install the Stop brackets provided in the kit to the lower hole on the inside of the Grab Bar using the bolts supplied in the kit.

Step 5

Install the front Grab Bar, use the bolts removed in step 3 using the top holes in the front Grab Bar as shown in figure 5.

Step 6

Install rear Grab Bar on the risers, use the bolts and nuts removed in step 2 and tighten.

Figure 6 show a completed installation of the Grab Bar Kit.

