



ETON America, LLC



Service Bulletin

Bulletin No:	0021
Date:	09/10/03

ATV Break-In Procedure

Your ATV requires a break-in period just as with all other internal combustion engines. This period allows the engine parts to seat and wear properly without undue strain which can cause premature failure.

1. For the first two weeks of operation do not run your ATV at full throttle for extended periods of time.
2. Viper 50M/50/70/90/90R
Your first tank of fuel should be a pre-mixture of fuel and oil at a 50:1 ratio. This will insure that the oil pump system has been primed and bled of air that may have occurred in shipping.
3. Viper Jr.
All fuel should be a pre-mixture of fuel and oil at a 50:1 ratio.
4. Do not operate the unit at more than 85% of maximum speed.
5. Do not over rev the engine.
6. Use light braking pressure to allow the brake pads to seat to the rotor and drums.

